




Instrucciones de montaje

Assembly instructions


8327/073, 2347/073
8328/073, 9328/073
8326/073, 9335/073



A | 1ud



B | 2ud



C | 1ud



D | 2ud



E | 2ud



F | 4ud



G | 12ud



H | 1ud






I | 1ud




J | 1ud


ZARA HOME




3.1




3.2




4.1




4.2




4.3




5.1




5.2




5.3





5.4




5.5



5.6



6.1



ZARA HOME